Unused
1
1
Receiver Control
(0xffff0000)
Interrupt
Enable
Ready

Unused
8
Receiver Data
(0xffff0004)
Received Byte


Unused
1
1
Transmitter Control
(0xffff0008)
Interrupt
Enable
Ready

Unused
8
Transmitter Data
(0xffff000c)
Transmitted Byte